

How to Use your New CASIO Projector.

3 input options currently set up for your new Casio Projector.

[Input Option 1](#) – **Elmo** (Listed under **Computer**)

[Input Option 2](#) – **Computer** plugged into dock (Listed under **HDMI 1**)

[Input Option 3](#) – **Wireless** connection (Listed under **Network**)

I want to use my Elmo!


Turn on Elmo and set to Elmo to Camera.

Turn on Projector and set input to Computer.

I want the old experience of my desktop back!

If you want the same functionality on your desktop and aren't going to take the laptop home. You can set up the laptop to close the lid and use the old desktop mouse, keyboard and screen alone. To do this you must change your power options, so you may close your laptop lid and have it not go to sleep.






Step 1: In the bottom right hand side of your screen, *right click* on the battery icon, and click on Power Options.



Step 2: Click on "Choose what closing the lid does"

Step 3: Change the option of "When I close the lid" to Do Nothing.

Power and sleep buttons and lid settings

	 On battery	 Plugged in
 When I press the power button:	Sleep ▾	Do nothing ▾
 When I press the sleep button:	Sleep ▾	Do nothing ▾
 When I close the lid:	Sleep ▾	Do nothing ▾

I want the old experience of using my laptop back!

This option is for you if you want to be able to pull something up on your laptop while displaying something different to your projector (EXTENDING your screen)

EASY Option: Click on your Windows button + P (for project) on your keyboard



Right click on your desktop background and go to display settings.

If you press the Windows Key and Letter P you will the following window to appear.

